



### Step 1

Attach tube to Bafflecap and attach Bafflecap to your 1-gallon bottle – we recommend used plastic bottles from windshield washer fluid, milk, or bleach.



### Step 2

Turn water off at main sprinkler valve.



### Step 3

Remove pea-drain cap; a small burst of water is normal.



#### Step 4

Attach tube firmly over waste port; if tube is difficult to attach, soften end in boiling water for 5 seconds.



#### Step 5

Open lower test-cock on backflow, starting the flow of water into your collection bottle.

**The**  
**B**afflecap  
**Products**

**1-800-583-9146**

3186 W Radcliff Drive  
Englewood CO 80110